

Capital Lock, Inc.

"Your Key to Security"

A10S F75



Passage Latch

Both knobs always unlocked.

A53PD F109



Entrance Lock

Turn/push-button locking; pushing and turning button locks outside knob, requiring use of key until button is manually unlocked. Push-button locking; pushing button locks outside knob until unlocked by key or by turning inside knob.

A25D



Exit Lock

Blank plate outside. Inside knob always unlocked.

A70PD F84



Classroom Lock

Outside knob locked and unlocked by key. Inside knob always unlocked.

A30D F77



Patio Lock

Push-button locking. Turning inside knob or closing door releases button, preventing lock-out.

A79PD



Communicating Lock

Locked or unlocked by key from outside. Blank plate inside.

A40S F76



Bath/Bedroom Privacy Lock

Push-button locking. Can be unlocked from outside with small screwdriver. Turning inside knob or closing door releases button.

A80PD F86



Storeroom Lock

Outside knob fixed. Entrance by key only. Inside knob always unlocked.

A43D F79



Communicating Lock

Turn-button in outer knob locks and unlocks knob and inside thumbturn.

A85PD F93



Hotel/Motel Lock

Outside knob fixed. Entrance by key only. Push-button in inside knob activates visual occupancy indicator, allowing only emergency masterkey to operate. Turning inside knob or closing door releases visual occupancy indicator. Rotation of inside spanner-button provides lock-out feature by keeping indicator activated.

A170



Single Dummy Trim

Dummy trim for one side of door. Used for door pull or as matching inactive trim.

D10S F75



Passage Latch

Both levers always unlocked.

D50PD F82



Entrance/Office Lock*

Push-button locking. Push-button locks outside lever until unlocked with key or by turning inside lever.

D12D F89



Exit Lock

Outside lever always fixed. Inside lever always unlocked.

D53PD F109



Entrance Lock*

Turn/push-button locking; pushing and turning use of key until button is manually unlocked. Push-button locking; pushing button locks outside lever until unlocked by key or by turning inside lever.

D12DEL



Electrically Locked (Fail Safe)

Outside lever continuously locked electrically. Unlocked by switch or power failure. Auxiliary latch deadlocks latchbolt when door is closed. Inside lever always free for immediate exit.

D60PD F88



Vestibule/Classroom Security Lock*

Latch retracted by key from outside when outside lever is locked by key in inside lever. Inside lever is always unlocked.

D12DEU



Electrically Unlocked (Fail Secure)

Outside lever continuously locked until unlocked by electric current. Auxiliary latch deadlocks latchbolt when door is closed. Inside lever always free for immediate exit.

D66PD F91



Store Lock**

Key in either lever locks or unlocks both levers.

D25D



Exit Lock

Blank plate outside. Inside lever always unlocked.

D70PD F84



Classroom Lock*

Outside lever locked and unlocked by key. Inside lever always unlocked.

D40S F76



Bath/Bedroom Privacy Lock

Push-button locking. Can be opened from outside with small screwdriver. Turning inside lever or closing door releases button.

D73PD F90



Corridor Lock*

Locked or unlocked by key from outside. Push-button locking from inside. Turning inside lever or closing door releases button.

D44S



Hospital Privacy Lock

Push-button locking. Unlocked from outside by turning emergency turn-button. Turning inside lever or closing door releases button.

D80PD F86



Storeroom Lock*

Outside lever fixed. Entrance by key only. Inside lever always unlocked.

D170



Single Dummy Trim

Dummy trim for one side of door. Used for door pull or as matching inactive trim.


D80PDEL



Electrically Locked (Fail Safe)*

Outside lever continuously locked electrically. Unlocked by key outside or by switch or power failure. Auxiliary latch deadlocks latchbolt when door is closed. Inside lever always free for immediate exit.

D80PDEU



Electrically Unlocked (Fail Secure)*

Outside lever continuously locked until unlocked by key or electric current. Auxiliary latch deadlocks latchbolt when door is closed. Inside lever always free for immediate exit.